

Seminar Room

AV Control Panel



POWER COMMANDS




Turns ON the presentation equipment – *selects **PC** mode by default.*

Switches OFF the presentation equipment – *press and hold.*



INPUT SELECTION



Selects the inbuilt **PC** as the input source - *press 'Windows+P' to choose a presentation display mode.*




Selects the **HDMI** lead as the input source – *connect the lead to a laptop to output video/audio.*



Selects the **USB-C** lead as the input source – *connect the lead to a laptop to output video/audio, whilst charging the device.*



Selects **Wireless Presentation** as the input source – *follow on-screen instructions to project wireless content from your device.*



Selects **Document Camera** as the input source – *present physical objects to your audience. This can also be used to connect a VGA device.*

NOTE: Pressing any of the above buttons when the system is OFF will switch the projector ON and start presenting from the chosen input.



AUDIO/VIDEO CONTROLS



Blanks the displayed image - *press to toggle Blank function on/off.*



Adjusts the **volume** of the speakers in the room – *the volume knob can also be used to make adjustments.*
